


**MTP**

**Table of Contents**

**INSTRUCTION MANUAL**

**Digital Multimeter  
Model MTP 2326**



**MTP Instruments Inc.**

<i>TITLE</i>	<i>PAGE</i>
<b>1. GENERAL INSTRUCTIONS</b>	<b>1</b>
1.1 Precaution safety measures	1
1.1.1 Preliminary	1
1.1.2 During use	2
1.1.3 Symbols	4
1.1.4 Instructions	4
1.2 Protection mechanisms	5
<b>2. DESCRIPTION</b>	<b>6</b>
2.1 Instrument Familiarization	6
2.2 LCD Display	7
2.3 Key pad	8
2.4 Terminals	9
2.5 Accessories	9
<b>3. FUNCTION DESCRIPTION</b>	<b>10</b>
3.1 General Functions	10
3.1.1 DATA HOLD mode	10
3.1.2 Battery saver	10
3.2 Measurement Functions	11
3.2.1 AC and DC Voltage measurement	11
3.2.2 Resistance measurement	12
3.2.3 Diode Test	12
3.2.4 Continuity Check	13

# Table of Contents

<b>TITLE</b>	<b>PAGE</b>
3.2.5 Capacitance measurement	14
3.2.6 Inductance measurement	14
3.2.7 Transistor measurement	15
3.2.8 Current measurement	15
<b>4. TECHNICAL SPECIFICATIONS</b>	<b>17</b>
4.1 General specifications..	17
4.2 Measurement specifications	17
4.2.1 DC Voltage	18
4.2.2 AC Voltage	18
4.2.3 Resistance	18
4.2.4 Diode Test	19
4.2.5 Continuity Check	19
4.2.6 Transistor	19
4.2.7 Inductance	19
4.2.8 Capacitance	19
4.2.9 DC Current	20
4.2.110AC Current	20
<b>5. MAINTENANCE</b>	<b>21</b>
5.1 General maintenance	21
5.2 Battery replacement	21

## 1. GENERAL INSTRUCTIONS

This instrument complies with IEC 61010-1, CAT. III 1000V and CAT.IV 600V overvoltage standards. See Specifications.

To get the best service from this instrument, read carefully this user's manual and respect the detailed safety precautions.

International symbols used on the Meter and in this manual are explained in chapter 1.1.3

### 1.1 Precautions safety measures

#### 1.1.1 Preliminary

\* Measurement category IV meters are designed to protect against transients from the primary supply level (overhead or underground utility service).

\* Measurement category III is for measurements performed in the building installation.

NOTE: Examples are measurements on distribution boards, circuit-breakers, wiring, including cables, bus-bars, junction boxes, switches, socket-outlets in the fixed installation, and equipment for industrial use and some other equipment, for example, stationary motors with permanent connection to the fixed installation.

\* Measurement category II is for measurements performed on circuits directly connected to the low voltage installation.

NOTE: Examples are measurements on household appliances, portable tools and similar equipment.

\* Measurement category I is for measurements performed on circuits not directly connected to MAINS.

NOTE: Examples are measurements on circuits not derived from MAINS, and specially protected (internal)

MAINS derived circuits. In the latter case, transient stresses are variable; for that reason, requires that the transient withstand capability of the equipment is made known to the user.

- \* When using this Multimeter, the user must observe all normal safety rules concerning:
  - protection against the dangers of electric current.
  - protection of the Multimeter against misuse.
- \* For your own safety, only use the test probes supplied with the instrument. Before use, check that they are in good condition.

### 1.1.2 During use

- \* If the meter is used near noise generating equipment, be aware that display may become unstable or indicate large errors.
- \* Do not use the meter or test leads if they look damaged.
- \* Use the meter only as specified in this manual; otherwise, the protection provided by the meter may be impaired.
- \* Use extreme caution when working around bare conductors or bus bars.
- \* Do not operate the meter around explosive gas, vapor, or dust.
- \* Verify a Meter's operation by measuring a known voltage. Do not use the Meter if it operates abnormally. Protection may be impaired. When in doubt, have the Meter serviced.
- \* Uses the proper terminals, function, and range for your measurements.
- \* When the range of the value to be measured is unknown, check that the range initially set on the multimeter is the highest possible or, wherever possible, choose the autoranging mode.

- \* To avoid damages to the instrument, do not exceed the maximum limits of the input values shown in the technical specification tables.
- \* When the multimeter is linked to measurement circuits, do not touch unused terminals.
- \* Caution when working with voltages above 60Vdc or 30Vac rms. Such voltages pose a shock hazard.
- \* When using the probes, keep your fingers behind the finger guards.
- \* When making connections, connect the common test lead before connecting the live test lead; when disconnecting, disconnect the live test lead before disconnecting the common test lead.
- \* Before changing functions, disconnect the test leads from the circuit under test.
- \* For all dc functions, including manual or auto-ranging, to avoid the risk of shock due to possible improper reading, verify the presence of any ac voltages by first using the ac function. Then select a dc voltage range equal to or greater than the ac range.
- \* Disconnect circuits power and discharge all high-voltage capacitors before testing resistance, continuity, diodes, or capacitance.
- \* Never perform resistance or continuity measurements on live circuits.
- \* Before measuring current, check the meter's fuse and turn off power to the circuit before connecting the meter to the circuit.
- \* In TV repair work, or when carrying out measurements on power switching circuits, remember that high amplitude

voltage pulses at the test points can damage the multimeter.  
Use of a TV filter will attenuate any such pulses.

- \* Use the 9V NEDA battery, properly installed in the Meter's battery case, to power the Meter.
- \* Replace the battery as soon as the battery indicator (  ) appears. With a low battery, the Meter might produce false readings that can lead to electric shock and personal injury.
- \* Do not measure voltages above 600V in Category IV, or 1000V in Category III installations.
- \* Do not operate the Meter with the case (or part of the case) removed.

### 1.1.3 Symbols:

Symbols used in this manual and on the instrument:

	<b>Caution:</b> refer to the instruction manual. Incorrect use may result in damage to the device or its components.
	AC (Alternating Current)
	DC (Direct Current)
	Earth ground
	Double insulated
	Fuse
	Conforms to European Union directives

### 1.1.4 Instructions

- \* Remove test leads from the Meter before opening the Meter case or battery cover.
- \* When servicing the Meter, use only specified replacement

parts.


- \* Before opening up the instrument, always disconnect from all sources of electric current and make sure you are not charged with static electricity, which may destroy internal components.
- \* Any adjustment, maintenance or repair work carried out on the meter while it is live should be carried out only by appropriately qualified personnel, after having taken into account the instructions in this present manual.
- \* A "qualified person" is someone who is familiar with the installation, construction and operation of the equipment and the hazards involved. He is trained and authorized to energize and de-energize circuits and equipment in accordance with established practices.
- \* When the instrument is opened up, remember that some internal capacitors can retain a dangerous potential even after the instrument is switched off.
- \* If any faults or abnormalities are observed, take the instrument out of service and ensure that it cannot be used until it has been checked out.
- \* If the meter is not going to be used for a long time, take out the battery and do not store the meter in high temperature or high humidity environment.

### 1.2 Protection mechanisms

- \* Fused by the fuse (FF400mA/1000V) during capacitance, Inductance, mA and hFE measurements.
- \* A PTC resistor protects against permanent overvoltages of up to 250V during resistance, continuity and diode test measurements.

## 2. DESCRIPTION

### 2.1 Instrument Familiarization



1 LCD display 2. Keypad 3. Rotary switch 4. Terminals

### 2.2 LCD Display

See Table 1 indicated for information about the LCD display.




Figure 1.Display

Table 1. Display Symbols

Symbol	Meaning
	The battery is low. <b>Warning:</b> To avoid false readings, which could lead to possible electric shock or personal injury, replace the battery as soon as the battery indicator appears.
	Indicates negative readings.
	Indicator for ac voltage or current. AC voltage and current are displayed as the average of the absolute value of the input, calibrated to indicate the equivalent rms value of a sine wave.
	Indicator for dc voltage or current.
	The Meter is in the Diode Test mode

**Table 1. Display Symbols (continued)**

	The Meter is in the Continuity Check mode.
	The Meter is in the Data Hold mode
<b>V, mV</b>	V: Volts. The unit of voltage. mV: Millivolt. $1 \times 10^{-3}$ or 0.001 volts.
<b>A, mA, <math>\mu</math>A</b>	A: Amperes (amps). The unit of current. mA: Milliamp. $1 \times 10^{-3}$ or 0.001 amperes. $\mu$ A: Microamp. $1 \times 10^{-6}$ or 0.000001 amperes
<b><math>\Omega</math>, k<math>\Omega</math>, M<math>\Omega</math></b>	$\Omega$ : Ohm. The unit of resistance. k $\Omega$ : Kilohm. $1 \times 10^3$ or 1000 ohms. M $\Omega$ : Megohm. $1 \times 10^6$ or 1,000,000 ohms.
<b>mH, H</b>	mH: The unit of Inductance 1H=1000mH H:
<b><math>\mu</math>F, nF</b>	F: Farad. The unit of capacitance. $\mu$ F: Microfarad. $1 \times 10^{-6}$ or 0.000001 farads. nF: Nanofarad. $1 \times 10^{-9}$ or 0.000000001 farads.

### 2.3 Keypad

See Table 2 indicated for information about the keypad operations.

**Table 2. Keypad**

Key	Function	Operation performed
	Any switch position	turn the meter on or off
<b>HOLD</b>	Any switch position	Press <b>HOLD</b> to enter and exit the Data Hold mode.
	Any switch position	Press  to turn the backlight on. After about 5 seconds, the backlight is auto-off.

### 2.4 Terminals

See Table 3 indicated for information about the terminals.

**Table 3. Terminals**

Terminal	Description
<b>COM</b>	Return terminal for all measurements. (Receiving the black test lead or the "com" plug of the special multi-function socket)
<b>V<math>\Omega</math>Hz</b>	Input for voltage, resistance, frequency, diode and continuity measurements. (Receiving the red test lead)
<b>mA</b> <b>hFE</b> <b>Lx</b>	Input for capacitance, Inductance, hFE and mA current measurements. (Receiving the red test lead or the "+" plug of the special multi-function socket)
<b>10A</b>	Input for 200mA to 10A current measurements. (Receiving the red test lead)

### 2.5 Accessories

Delivered with the multimeter:

- |                                 |           |
|---------------------------------|-----------|
| ∞ User's manual                 | One piece |
| ∞ Test leads                    | One piece |
| ∞ Carry case                    | One piece |
| ∞ Special Multi-function socket | One piece |

### 3. FUNCTION DESCRIPTION

#### 3.1 General Functions

##### 3.1.1 DATA HOLD mode

Data Hold mode makes the meter stop updating the display. Data Hold function can be cancelled by changing the measurement mode, or push **HOLD** key again.

To enter and exit the Data Hold mode:

1. Press **HOLD** key. Fixes the display on the current value,  is displayed.
2. A second short press returns the meter to normal mode.

##### 3.1.2 Battery Saver

Turn on the meter. And then The Meter will be turned off automatic after approx. 20 minutes.

### 3.2 Measurement Functions

#### 3.2.1 AC and DC Voltage measurement



*To avoid electrical shock and/or damage to the instrument, do not attempt to take any voltage measurement that might exceeds 1000Vdc or 750Vac rms.*

*To avoid electrical shock and/or damage to the instrument, do not apply more than 1000Vdc or 750Vac rms between the common terminal and the earth ground.*

Voltage is the difference in electrical potential between two points.

The polarity of ac (alternating current) voltage varies over time; the polarity of dc (direct current) voltage is constant.

The Meter's DC voltage ranges are 200.0mV, 2.000V, 20.00V, 200.0V and 1000V; AC voltage ranges are 2.000V, 20.00V, 200.0V and 7500V.

To measure ac or dc voltage:

1. Set rotary switch to the proper range.
2. Connect the black and red test leads to the COM and V terminals respectively.
3. Connect the test leads to the circuit being measured
4. Read the displayed value. The polarity of red test lead connection will be indicated when making a DCV measurement.

#### NOTE:

- ∞ Unstable display may occur especially at DC200mV and AC2V ranges, even though you do not put test leads into input terminals, in this case, if an erroneous reading is suspected, short the V terminal and the COM terminal, and make sure the zero display.

### 3.2.2 Resistance measurement

**⚠ To avoid electrical shock and/or damage to the instrument, disconnect circuit power and discharge all high-voltage capacitors before measuring resistance.**

Resistance is an opposition to current flow.

The unit of resistance is the ohm ( $\Omega$ ).

The Meter's resistance ranges are 200.0 $\Omega$ , 2.000k $\Omega$ , 20.00k $\Omega$ , 200.0k $\Omega$ , 2.000M $\Omega$ , 20.00M $\Omega$  and 200.0M $\Omega$ .

To measure resistance:

1. Set the rotary switch to proper range.
2. Connect the black and red test leads to the **COM** and  $\Omega$  terminals respectively.
3. Connect the test leads to the circuit being measured and read the displayed value.

#### Some tips for measuring resistance:

- ∞ The measured value of a resistor in a circuit is often different from the resistor's rated value. This is because the Meter's test current flows through all possible paths between the probe tips.
- ∞ In order to ensure the best accuracy in measurement of low resistance, short the test leads before measurement and memory the test probe resistance in mind. This necessary to subtract for the resistance of the test leads.
- ∞ On 20M $\Omega$  and 200M $\Omega$  ranges, the meter may take a few seconds to stabilize reading. This is normal for high resistance measuring.
- ∞ When the input is not connected, i.e. at open circuit, the figure "1" will be displayed for the overrange condition.

### 3.2.3 Diode Test

**⚠ To avoid electrical shock and/or damage to the instrument, disconnect circuit power and discharge all high-voltage capacitors before testing diodes.**

Use the diode test to check diodes, and other semiconductor devices. The diode test sends a current through the semiconductor junction, and then measures the voltage drop across the junction; a good silicon junction drops between 0.5V and 0.8V.

To test a diode out of a circuit:

1. Set the rotary switch to **▶+** range.
2. Connect the black and red test leads to the **COM** and **▶+** terminals respectively.
3. For forward-bias readings on any semiconductor component, place the red test lead on the component's anode and place the black test lead on the component's cathode.
4. The meter will show the approx. forward voltage of the diode. If the test lead connection is reversed, only figure "1" displayed.

In a circuit, a good diode should still produce a forward bias reading of 0.5V to 0.8V; however, the reverse-bias reading can vary depending on the resistance of other pathways between the probe tips.

### 3.2.4 Continuity Check

**⚠ To avoid electrical shock and/or damage to the instrument, disconnect circuit power and discharge all high-voltage capacitors before testing for Continuity.**

Continuity is a complete path for current flow.

The beeper sounds if a circuit is complete. These brief contacts cause the Meter to emit a short beep.

To test for continuity:

1. Set the rotary switch to **▶** range.
2. Press the yellow key twice to activate Continuity Check.
3. Connect the black and red test leads to the COM and  $\Omega$  terminals respectively.

4. Connect the test leads to the resistance in the circuit being measured.
5. When the test lead to the circuit is below approx. 30Ω, a continuous beeping will indicate it.

**Note:**

∞ Continuity test is available to check open/short of the circuit.

### 3.2.5 Capacitance measurement

 *To avoid electrical shock and/or damage to the instrument, disconnect circuit power and discharge all high-voltage capacitors before measuring capacitance. Use the dc voltage function to confirm that the capacitor is discharged.*

Capacitance is the ability of a component to store an electrical charge.

The unit of capacitance is the farad (F). Most capacitors are in the nanofarad to microfarad range.

The Meter's capacitance ranges are 20.00nF, 200.0nF, 2.000μF, and 200.0μF.

To measure capacitance:

1. Set the rotary switch to proper range.
2. Connect the black and red test leads to the **COM** and **⊕** terminals respectively
3. Connect the test leads to the capacitor being measured and read the displayed value.

**Some tips for measuring capacitance:**

- ∞ The meter may take a few seconds to stabilize reading. This is normal for high capacitance measuring.
- ∞ To improve the accuracy of measurements less than 20nF, subtract the residual capacitance of the Meter and leads.

### 3.2.6 Inductance measurement

The unit of **Inductance** is the farad (H). The Meter's **Inductance** ranges are 20.00mH, 200.0mH, 2.000H, and 20.00H.

To measure **Inductance**:

1. Set the rotary switch to proper range.
2. Connect the black and red test leads to the **COM** and **LX** terminals respectively
3. Connect the test leads to the **Inductance** being measured and read the displayed value.

### 3.2.7 Transistor measurement

 *To avoid electrical shock and/or damage to the instrument, do not apply more than 250Vdc or 250Vac rms between the hFE terminal and the COM terminal.*

1. Set the rotary switch to **hFE** range.
2. Connect the "com" plug and "+" plug of the special multi-function socket to the **COM** and **hFE** terminals.
3. Determine whether the transistor to be tested is NPN or PNP type and locate the Emitter, Base and Collector leads.
4. Insert leads of the transistor into proper holes of the special multi-function socket.
5. The meter will show the approx. hFE value at test condition of base current 10 μ A and Vce 2.8V.

### 3.2.8 Current measurement

 *To avoid damage to the Meter or injury if the fuse blows, never attempt an in-circuit current measurement where the open-circuit potential to earth is greater than 250V. To avoid damage to the meter, check the meter's fuse before proceeding. Use the proper terminals, function, and range for your measurement. Never place the test leads in parallel with a circuit or component when the leads are plugged into the current terminals.*

Current is the flow of electrons through a conductor.

The Meter's DC current ranges are 200.0mA and 10.00A;

AC current ranges are 200.0mA and 10.00A.

To measure current:

1. Turn off the power of the measured circuit. Discharge all the high voltage capacitors.
2. Set the rotary switch to the proper range.
3. Connect the black test lead to the COM terminal and the red test leads to the mA terminal for a maximum of 200mA. For a maximum of 10A, move the red test lead to the 10A terminal.
4. Break the circuit path to be tested.  
Connect the black test lead to the more negative side of the break; connect the red test lead to the more positive side of the break. (Reversing the leads will give a negative reading, but will not damage the Meter.)
5. Turn on the power of the measured circuit, and then read the display. Be sure to note the measurement units at the right side of the display (mA or A). When only the figure "1" displayed, it indicates overrange situation and the higher range has to be selected.
6. Turn off the power of the measured circuit and discharge all the high voltage capacitors. Remove the test leads and recover the measured circuit.

## 4 TECHNICAL SPECIFICATIONS

### 4.1 GENERAL SPECIFICATIONS

- ∞ Environment conditions:  
1000V CAT. III and 600V CAT.IV  
Pollution degree: 2  
Altitude < 2000m  
Operating temperature:  
0~40°C, 32°F~122°F (<80% RH, <10°C noncondensing)  
Storage temperature:  
-10~60 °C, 14°F~140°F (<70% RH, battery removed)
- ∞ Temperature Coefficient:  
0.1×(specified accuracy) / °C (<18°C or >28°C)
- ∞ MAX. Voltage between terminals and earth ground:  
750V AC rms or 1000V DC.
- ∞ Fuse Protection: mA: fuse (FF400mA/1000V)  
A: fuse (FF10A/500V)
- ∞ Sample Rate: 3 times/sec for digital data.
- ∞ Display: 3 1/2 digits LCD display. Automatic indication of functions and symbols.
- ∞ Over Range indication: LCD will display "1".
- ∞ Low battery indication:  
The "" is displayed when the battery is under the proper operation range.
- ∞ Polarity indication: "-" displayed automatically.
- ∞ Power source: 9V 
- ∞ Battery type: NEDA 1604, 6F22, or 006P.
- ∞ Dimensions: 188(L)×92(W)×50(H) mm.
- ∞ Weight: 380g. Approx. (battery included).

### 4.2 Measurement specifications

Accuracy is specified for one year after calibration, at operating temperatures of 18 °C to 28 °C , with relative humidity at 0% to 75%.

Accuracy specifications take the form of:  $\pm$ (% of Reading + Number of Least Significant Digits)

#### 4.2.1 DC Voltage

Range	Resolution	Accuracy
200mV	0.1mV	$\pm$ (0.5% of rdg +1 digit)
2V	1mV	
20V	10mV	
200V	100mV	
1000V	1V	$\pm$ (0.8% of rdg +2 digits)

Input impedance: 10M $\Omega$

Max. input voltage: 250Vdc or ac rms for 200mV range and 1000Vdc or 750V ac rms for other ranges,

#### 4.2.2 AC Voltage

Range	Resolution	Accuracy
2V	1mV	$\pm$ (0.8% of rdg +3 digits)
20V	10mV	
200V	100mV	
750V	1V	$\pm$ (1.2% of rdg +3 digits)

Input impedance: 10M $\Omega$

Max. input voltage: 250Vdc or ac rms for 200mV range and 1000Vdc or 750V ac rms for other ranges,

Frequency Range: 40Hz-400Hz ranges.

Response: Average, calibrated in rms of sine wave

#### 4.2.3 Resistance

Range	Resolution	Accuracy
200 $\Omega$	0.1 $\Omega$	$\pm$ (0.8% of rdg+3 digits)
2k $\Omega$	1 $\Omega$	$\pm$ (0.8% of rdg+1 digit)
20k $\Omega$	10 $\Omega$	
200k $\Omega$	100 $\Omega$	
2M $\Omega$	1k $\Omega$	
20M $\Omega$	10k $\Omega$	$\pm$ (1.0% of rdg+2 digits)
200M $\Omega$	0.1M $\Omega$	$\pm$ [5.0% +10 digits]

Overload protection: 250V dc or 250Vac rms.

Open Circuit Voltage: Less than 700mV.

#### 4.2.4 Diode

Range	Resolution	Function
	1mV	Display read approx. forward voltage of diode

Forward DC Current: approx. 1mA

Reversed DC Voltage: approx. 2.8V

Overload protection: 250Vdc or 250Vac rms.

#### 4.2.5 Audible continuity

Range	Continuity beeper
	$\leq$ 30 $\Omega$

Test Current: approx. 1mA

Reversed DC Voltage: approx. 2.8V

Overload protection: 250Vdc or 250Vac rms.

#### 4.2.6 Transistor

Range	Description	Test Condition
hFE	Display read approx. HFE value (0-1000) of transistor under test (all type).	Base Current approx. 10 $\mu$ A, Vce approx. 2.8V.

#### 4.2.7 Inductance

Range	Resolution	Accuracy
20mH	0.01mH	(3.0%rdg + 5dgt)
200mH	0.1mH	(3.0%rdg + 5dgt)
2H	1mH	(3.0%rdg + 5dgt)
20H	10mH	(3.0%rdg + 5dgt)

Overload protection: fuse (FF400mA/1000V).

#### 4.2.8 Capacitance

Range	Resolution	Accuracy
20nF	10pF	$\pm$ (4.0% of rdg+3 digits)
200nF	0.1nF	
2 $\mu$ F	1nF	
200 $\mu$ F	100nF	$\pm$ (5.0% of rdg+10 digits)

Overload protection: fuse (FF400mA/1000V).

#### 4.2.9 DC Current

Range	Resolution	Accuracy
200mA	0.1mA	$\pm(1.5\% \text{ of rdg}+1 \text{ digit})$
10A	10mA	$\pm(2.0\% \text{ of rdg}+5 \text{ digits})$

Overload protection: fuse (FF400mA/1000V). 10A range fuse (FF10A/500V)

Max. input current: 200mA dc or 200mA ac rms for mA range, 10A dc or 10A ac rms for 10A ranges.

For measurements >5A, 10 Seconds maximum ON to measure 1 minutes OFF; Above 10A unspecified.

#### 4.2.10 AC Current

Range	Resolution	Accuracy
200mA	0.1mA	$\pm(1.8\% \text{ of rdg}+3 \text{ digits})$
10A	10mA	$\pm(3.0\% \text{ of rdg}+7 \text{ digits})$

Overload protection: fuse (FF400mA/1000V). 10A range fuse (FF10A/500V)

Max. input current: 200mA dc or 200mA ac rms for mA range, 10A dc or 10A ac rms for 10A ranges.

For measurements >5A, 10 Seconds maximum ON to measure 1 minutes OFF; Above 10A unspecified.

Frequency Range: 40Hz-400Hz

Response: Average, calibrated in rms of sine wave

## 5. MAINTENANCE

Do not attempt to repair or service your Meter unless you are qualified to do so and have the relevant calibration, performance test, and service information.

### 5.1 General Maintenance

 **To avoid electrical shock or damage to the meter, do not get water inside the case. Remove the test leads and any input signals before opening the case**

Periodically wipe the case with a damp cloth and mild detergent. Do not use abrasives or solvents.

Dirt or moisture in the terminals can affect readings.

To clean the terminals:

- ∞ Turn the meter off and remove all test leads.
- ∞ Shake out any dirt that may be in the terminals.
- ∞ Soak a new swab with a cleaning and oiling agent (such as WD-40).
- ∞ Work the swab around in each terminal. The oiling agent insulates the terminals from moisture-related contamination.

### 5.2 Battery and Fuse replacement

 **To avoid false readings, which could lead to possible electric shock or personal injury, replace the battery as soon as the battery indicator (  ) appears.**

**Use only fuses with the amperage, interrupt, voltage And speed ratings specified**

**FF400mA/1000V Min interrupt rating 10000A**

**FF10A/500V Min interrupt rating 10000A**

To replace the battery or fuse:

- ∞ Turn the meter off.
- ∞ Disconnect test leads and/or any connectors from the

terminals.

- ∞ Use a screwdriver to unscrew the two screws secured on the battery cover.
- ∞ Take out the battery cover from the meter.
- ∞ Remove the used batteries or damaged fuse.
- ∞ Replace with the new 9V batteries (6F22) or new fuse.
- ∞ Rejoin the battery cover and secure by the two screws.

**⚠ CAUTION**

***Using this appliance in an environment with a strong radiated radio-frequency electromagnetic field (approx. 3V/m), may influence its measuring accuracy. The measuring result can be strongly deviating from the actual value.***

**Les Instruments**

**MTP**

**Instruments**

**Head Office**

**4409, Charleroi street**

**Montreal-North, Quebec**

**H1H 1T6**

**Telephone: (514) 326-7167 Fax: (514) 326-7838**

**Toll Free Number: 1-888-326-7167**

**Web Site: [www.mtpinc.com](http://www.mtpinc.com)**

**E-mail: [info@mtpinc.com](mailto:info@mtpinc.com)**

**Distributed by:**

